

Installation Guide Solo™

For Single Shower Doors



NEED EXPERT HELP? CALL US [1-866-452-7707](tel:1-866-452-7707)



Installation Guide Solo™ - Single Shower Door

Installation: Two People are required to install this product

Tools Needed:

Shims with different thickness
72" Level
48" Level
5/16" diamond tipped drill bit,
Tape Measure
Phillips Screwdriver bit
Drill and/or Screw Gun
Caulk gun
Silicone
Painters tape

Wire Cutters
Tape measure
Suctions cups
Drop cloth,
Pencil
Rubber mallet or soft block of wood
Hammer
Utility Knife

1. Remove existing Door and all debris
 - a. **STOP** - if any tiles are broken or cracked you must fixed before proceeding
2. If no door present - make sure tiles are clean of all debris and/or soap
3. Take painters tape and tape the middle of the threshold
4. Measure and Find center of the threshold
5. Mark those points on painters tape
6. Open all boxes and check the hardware and glass for damage
STOP if any damage or incorrect or missing parts

Door Install

7. Open package for the door and set door to the side
8. Check Hardware and door for damage
 - a. **STOP** if any part is damaged
9. Place 7/16" shims in 2 places on threshold to support door placement
10. Set door in place on the shims on the center of the threshold
11. Use 1/4" shims to leave that gap on both sides of the door
12. Take the 12" long piece of sweep out and place on the fixed panel and door to align
13. Add shims to center and align door
14. Center bottom of door
15. Take hinges out and separate the plates (no need for siliconing plastic seals in place)
16. Put hardware on with screw opening facing in towards the shower
17. Mark all holes
18. Remove the door and set to the side carefully
19. Drill holes
 - a. PRO Tip: use a wet towel to catch debris when drilling
20. Silicone holes
21. Insert anchors
 - a. Tap in with rubber mallet (or cover with a wood block and tap lightly with hammer)

NEED EXPERT HELP? CALL US 1-866-452-7707



- b. Cut heads off anchors
- 22. Set door in place and put the 12" strip on the fixed and door panel
 - a. Make sure of alignment
- 23. Screw hinges down
- 24. Tighten Set Screws to all hinges
- 25. Install wall seal before removing shims
 - a. From inside the shower peel back 3" of top self stick paper
 - b. Slide into place and align
 - c. Slowly peel back the rest of the backing paper and press into place
- 26. REMOVE SHIMS BEFORE OPENING DOOR
- 27. Measure and cut all seals and sweeps
- 28. Clean clean glass edges
- 29. Take door handle apart using the provided allen wrench
 - a. Install the door handle
- 30. Setting Door closer adjustment**
- 31. Remove caps on hinge
- 32. Loosen adjustment screws with allen wrench by 1 turn ↻
- 33. Close ½ way to a 45 degree angle
 - a. Now tighten the screws down all the way ↻
- 34. Install all seals and sweeps
 - a. PRO TIP: take the edge of the caulk tube to slide the seals down
- 35. Clean all glass
- 36. Silicone all wall and door seals and hinges on the door panel
- 37. WAIT 24 HOURS before using the shower.

Issue

If door does not fully seal

- 1. From inside shower take caps off of the inside of hinge
- 2. Take allen wrench and loosen screws by 1 full turn ↻
- 3. Open the door fully and close a minimum of 3 times
- 4. Then open door ½ of the way to 90 degrees
- 5. Tighten ↻adjustment screws down all the way
- 6. Shut the door to make sure it seals

NEED EXPERT HELP? CALL US 1-866-452-7707

