

Installation Guide Tela™

For Fixed & Swingable Shower Screens



NEED EXPERT HELP? CALL US [1-866-452-7707](tel:1-866-452-7707)



Installation Guide Tela™ - Fixed Shower Screens

Installation: Two People are required to install this product

Tools Needed:

Shims with different thickness

72" Level

48" Level

5/16" diamond tipped drill bit,

Tape Measure

Phillips Screwdriver bit

Drill and/or Screw Gun

Caulk gun

Silicone

Painters tape

Wire Cutters

Tape measure

Suctions cups

Drop cloth,

Pencil

Rubber mallet or soft block of wood

Hammer

Utility Knife

1. Remove existing Door and all debris
 - a. **STOP** - if any tiles are broken or cracked you must fixed before proceeding
2. If no door present - make sure tiles are clean of all debris and/or soap
3. Take painters tape and tape the middle of the threshold
4. Measure and Find center of the threshold
5. Mark those points on painters tape
6. Open all boxes and check the hardware and glass for damage

STOP if any damage or incorrect or missing parts

FIXED PANEL INSTALLATION

7. Next open the box with the fixed panel
8. Check Hardware and door for damage
 - a. **STOP** if any part is damaged
9. Take lid and use as a protective barrier for the floor - be sure to cut out the sections with any packing staples
10. Lay Down drop cloth in shower
11. Remove glass front the box and place close to shower with the notched side on the ground with staple free cardboard under it, leaning on a section of staple free cardboard or towel
12. Measure the base of the fix panel to determine shim placement on threshold shims should be 1" from the edge of the glass corners
13. Place at least 1/8 shims on the threshold
14. Place the fixed panel on the shims on the center of the threshold
15. Remove one 1/16" shim from each side of the bottom and Level the Panel
16. Mark the location of the glass on the threshold
17. Level the side and mark
18. Take clamp with the screw opening facing inward and set in notches and mark holes
19. Measure the door opening to check door opening is correct
20. Remove panel and set to the side

NEED EXPERT HELP? CALL US 1-866-452-7707



21. Drill to the anchor depth
22. Wipe all debris
 - a. PRO TIP: use a wet towel to catch debris when drilling
23. Silicone all holes before inserting anchors
24. Insert anchors
 - a. Tap in with rubber mallet (or cover with a wood block and tap lightly with hammer)
 - b. Cut the anchor heads off
25. Silicone into the anchors
26. Silicone the plastic seals to the clamp before setting them in place
27. Set all clamps in place and screw done with provided screws
28. Set glass in place & Remove the black shims and replace with small clear shims
29. Tighten to clamp down and that will hold glass in place
30. Silicone clamp opening
31. Tighten bottom clamps

NEED EXPERT HELP? CALL US [1-866-452-7707](tel:1-866-452-7707)



Installation Guide Tela™ - Swingable Shower Screens

Installation: Two People are required to install this product

Tools Needed:

Shims with different thickness	Wire Cutters
72" Level	Tape measure
48" Level	Suctions cups
5/16" diamond tipped drill bit,	Drop cloth,
Tape Measure	Pencil
Phillips Screwdriver bit	Rubber mallet or soft block of wood
Drill and/or Screw Gun	Hammer
Caulk gun	Utility Knife
Silicone	
Painters tape	

1. Remove existing Door and all debris
 - a. **STOP** - if any tiles are broken or cracked you must fixed before proceeding
2. If no door present - make sure tiles are clean of all debris and/or soap
3. Take painters tape and tape the middle of the threshold
4. Measure and Find center of the threshold
5. Mark those points on painters tape
6. Open all boxes and check the hardware and glass for damage
STOP if any damage or incorrect or missing parts

Swinging Panel Install

7. Open package for the door and set door to the side
8. Check Hardware and door for damage
 - a. **STOP** if any part is damaged
9. Place 7/16" shims in 2 places on threshold to support door placement
10. Set door in place on the shims on the center of the threshold
11. Use 1/4" shim to leave that gap between glass and wall
12. Take the 12" long piece of sweep out and place on the fixed panel and door to align
13. Add shims to center and align door
14. Center bottom of door
15. Take hinges out and separate the plates (no need for siliconing plastic seals in place)
16. Put hardware on with screw opening facing in towards the shower
17. Mark all holes
18. Remove the door and set to the side carefully
19. Drill holes
 - a. PRO Tip: use a wet towel to catch debris when drilling
20. Silicone holes
21. Insert anchors
 - a. Tap in with rubber mallet (or cover with a wood block and tap lightly with hammer)

NEED EXPERT HELP? CALL US 1-866-452-7707



- b. Cut heads off anchors
- 22. Set door in place and put the 12" strip on the fixed and door panel
 - a. Make sure of alignment
- 23. Screw hinges down
- 24. Tighten Set Screws to all hinges
- 25. REMOVE SHIMS BEFORE OPENING DOOR
- 26. Measure and cut all seals and sweeps
- 27. Clean clean glass edges
- 28. Install Door seal only
- 29. Take door handle apart using the provided allen wrench
 - a. Install the door handle
- 30. Install all seals and sweeps
 - a. PRO TIP: take the edge of the caulk tube to slide the seals down
- 31. Clean all glass
- 32. Silicone all seals and hinges on the door panel
- 33. WAIT 24 HOURS before using the shower.

NEED EXPERT HELP? CALL US [1-866-452-7707](tel:1-866-452-7707)

